



Manual / Anleitung

Slide Rutsche

Support

**If you need help with assembly
or have questions about our
products: Just send us a message.
We're happy to help.**

Falls du Hilfe bei der Montage brauchst
oder Fragen zum Produkt hast: Schreib
uns einfach. Wir helfen dir
gerne weiter:

support@bloc-frame.com

Art. No.: C-02-010

Version: V1 - June 2026

 bloc-frame.com

 support@bloc-frame.com

 Follow us on Instagram!

**play.
move.
grow.
together.**

Make it yours

The Frame is your foundation – our modules are the extension. They integrate easily and adapt flexibly to your daily routine.

Thanks for supporting our young brand and bringing movement outdoors.

Der Frame ist die Basis – unsere Module sind die Ergänzung. Sie lassen sich einfach integrieren und passen sich flexibel eurem Alltag an.

Danke, dass du unsere junge Brand unterstützt und Bewegung nach draußen bringt.




Level up your bloc frame! Check out more upgrades on our website.

Upgrade deinen bloc frame! Entdecke weiteres Zubehör auf unserer Website.


www.bloc-frame.com




Parts list / Teileübersicht




Screws / Schrauben




Orientation A








Orientation B







Orientation C






































Ready to play!

EN Warnings

General Warnings

Read and understand all instructions before use. Failure to follow these warnings can result in serious injury or death. Read this manual in combination with the Bloc frame manual.

- For domestic use only.
- For outdoor use only.
- Adult supervision required.
- Not suitable for children under 3 years.
- Falling hazard – Platform height: 150 cm.
- Maximum user weight on the platform: 70 kg.
- Maximum user weight on the slide: 70 kg.
- The platform and slide are designed for children's use only. Users who are too large to safely access, use or leave the platform and slide must not use the product.
- Adult assembly required.
- Ensure adequate impact-absorbing surfacing beneath and around the platform and slide.
- Keep the area beneath and around the platform and slide free from obstacles.
- The product may become hot in direct sunlight.
- Install the platform and slide only as shown in these instructions.

Safe Use – Platform

- The platform is only suitable for assembly on the ladder side of the Bloc frame.
- The platform may only be accessed using the designated access points.
- Do not use the platform if the fabric cover is damaged, loose, missing or incorrectly installed. Immediately stop using the platform if the fabric cover becomes detached during use.
- Ensure the fabric cover completely covers the opening between the platform and the climbing frame.
- Do not use the product if any components are damaged, worn or missing.
- Do not use the platform to access the top frame.
- Do not stand, sit or climb on guardrails of the platform.
- The assembly must be carried out in such a way that head, finger and clothing entrapment hazards are avoided.

Safe Use – Slide

- The slide is only suitable for assembly on the Bloc platform and may only be used when correctly attached to the platform.
- Keep fire and other heat sources away from the product.
- Do not lift, move or reposition the slide after it has been attached to the platform. The slide could be damaged and break.
- Position the slide so that it is not exposed to prolonged direct sunlight.
- Check the slide temperature before use in warm weather.
- Do not attach swings, trapezes, ropes or other accessories with long ropes next to the slide due to possible strangulation hazards.
- Keep the slide exit area clear at all times.
- The slide shall not be installed over concrete, asphalt or any other hard surface.
- Install the slide on a level, impact-absorbing surface at least two metres away from any obstruction such as a fence.
- Ensure the slide is securely attached to the platform before use.
- Do not use the slide if any attachment points are damaged, loose or missing.
- Do not use the slide if cracks, deformation or other damage are present.

User Guidelines

SaleLab or its distributors assume no liability for injuries or damages resulting from improper or unauthorized use of this product. Use this bloc product only in accordance with this manual. Any unauthorized use may result in serious injury or product damage.

This accessory is exclusively designed for use with a bloc climbing frame. Always read and follow the instructions and safety guidelines provided in the main bloc Frame manual.

Maintenance

To ensure safety, this product must be inspected regularly. Failure to perform regular maintenance can cause the product to become a hazard.

Immediately replace the product if any wear or defects are found.

Before each use:

- Check the platform, slide, fabric cover and all attachment points for damage, wear or loosening.
- Ensure the fabric cover is correctly installed and securely attached.
- Check all hook-and-loop fasteners.
- Ensure the slide is securely attached to the platform.
- Ensure the slide exit area is free from obstacles.

Monthly:

- Inspect all structural components and attachment points for wear.
- Check all nuts, bolts and fasteners for tightness.
- Replace damaged components immediately according to the manufacturer's instructions.

Cleaning:

Clean the product only with a damp cloth and lukewarm water.

Do not use chemical detergents, soaps, solvents, or hot water.

Storage:

Protect the product from continuous sunlight (UV light), moisture, and freezing temperatures.

Disposal:

Follow local regulations and guidelines for proper disposal.

Warranty

Improper use or incorrect application of the product is expressly prohibited and releases the manufacturer from any liability. Modifications to the original product are not permitted and will void the warranty. As the owner of this Bloc product, you have the following warranty:

The product has a 2-year warranty from the date of purchase.

Further warranty terms and conditions can be found at: bloc-frame.com

Warranty conditions:

You can only make warranty claims upon presentation of the original proof of purchase. The warranty covers only defects in materials and workmanship. It is void if:

- The product has been used improperly or negligently.
- The product has been modified.
- The use is not in accordance with its intended purpose.
- Visual defects (discoloration, fading) are caused by weather influences.

Normal wear and tear of ropes, textile components and hook-and-loop fasteners is excluded from the warranty.

